

# Mounting A Multi-Lock to a timber barrier

The existing timber post is trimmed down square so that the barrier beam will pass over the top without catching, the catch is then bolted onto the beam using M10 coach bolts and shear nuts (see securing details below). The Multi-Lock body is then offered up to the catch and bolted into place on the post using the same fixing details as the catch. Up to 5 or up to 10 users can then be installed, users can be added or removed at will on a temporary or permanent basis.

